



For the version without covering,
please contact: sales@alorair.com

28	Handle fixed cover		1
27	Compressor		1
26	Evaporator top foam		1
25	Humidity sensor		1
24	Two fixed strips		1
23	Electric control box component		1
22	Condenser		1
21	High Pressure pipe component		1
20	Return pipe component		1
19	Water Pump		1
18	Wind circle	Galvanized sheet	1
17	Operation panel		1
16	Motor		1
15	Motor bracket	Galvanized sheet	1
14	Air outlet grille	Stainless steel	1
13	Air outlet deck	Plastic	4
12	Air outlet cover	Stainless steel	1
11	Lower Housing	Plastic	1
10	Wheel	Rubber	2
9	Axle bracket	45 Steel	1
8	Foot Pad	Rubber	4
7	Evaporator	Copper	1
6	MERV-8 Filter		1
5	Air inlet panel	Galvanized sheet	1
4	Handle		1
3	Power Cable		1
2	Water Pipe	PVC	1
1	Upper Housing	Plastic	1
No.	Name	Material	Quantity

— Restoration & Moisture & Ventilation —



SPARE PARTS LIST

Storm LGR 850X